


Worlds largest selection of styles and sizes of plastic pallets available. Visit [www.pallets.com](http://www.pallets.com) to see them all.

- Designed for the newest sheetfed presses
- Attention given to the latest advances in automation for continuous feed and delivery
- Provided as OEM equipment with many new presses
- Safe
- HACCP/USDA/FDA approved
- Lasts 10+ Years
- Reduces Spoilage
- Cost Effective
- Easy to Use
- Efficient

**Stratis**<sup>®</sup>  
a rotonics manufacturing brand



Compatible With:

**BOBST**

**KOMORI**



**KBA**

**manroland**

**ASITRADE**



**MITSUBISHI**

**HEIDELBERG**



**Rotonics Manufacturing, Inc.**

**1-800-PALLETS (725-5387) or 1-317-328-8000**

**[sales@pallets.com](mailto:sales@pallets.com)**

**BOBST EQUIPMENT****Stratis Pallet**

SP 76 E, 76-BM / Commercial 76.....	P3022RS00
<i>Manual Non-stop</i>	
SP 102, 103, 104, Foilmaster 102.....	P4029RS00
<i>Manual Non-stop</i>	
SP 102 CE, 102 CER, 102-BMA.....	P4029RS00
<i>Manual Non-stop</i>	
SP 102 CE, CER.....	P4029RS00-A
<i>Automatic Non-stop</i>	
SP 104 E, ER.....	P4029RS00
<i>Manual Non-stop</i>	
SP 104 E, ER.....	P106RS00-A
<i>Automatic Non-stop</i>	
Foilmaster 104-/ FR / Visionfoil 104/ Expertcut 104 FR.....	P4029RS00
<i>Manual Non-stop</i>	
SPeria 106, 106 E / Novacut 106-/E.....	P4029RS00
<i>Manual Non-stop</i>	
SPeria 106, 106 E.....	P106RS00-A
<i>Automatic Non-stop</i>	
SPanthera 106 LE, 106 LER.....	P4029RS00
<i>Manual Non-stop</i>	
SPanthera 106 LE, 106 LER.....	P106RS00-A
<i>Automatic Non-stop</i>	
Visioncut 106 LE.....	P4029RS00
<i>Manual Non-stop</i>	
Expertcut 106 LE/LER/PE/PER.....	P4029RS00
<i>Manual Non-stop</i>	
Expertcut 106 LE/LER/PE/PER.....	P106RS00-A
<i>Automatic Non-stop</i>	
SPrintera 106 PER.....	P4029RS00
<i>Manual Non-stop</i>	
SPrintera 106 PER.....	P106RS00-A
<i>Automatic Non-stop</i>	
	P108RS108-Ab
	P120RS120-A
Mastercut 106 PER.....	P106RS00-A
<i>Manual Non-stop</i>	
Mastercut 106 PER.....	P106RS00-A
<i>Automatic Non-stop</i>	
SP 130, 126-BMA.....	P5038RS00
<i>Manual Non-stop</i>	
SP 130 E, 130 ER.....	P5539RS00-A
<i>Automatic Non-stop</i>	
SP 142 CER / SP 1420.....	P5539RS00
<i>Manual Non-stop</i>	P5640RS28
SP 142 CER.....	P5539RS00-ACER
<i>Automatic Non-stop</i>	
SPeria 142 E / SP 142 ER.....	P5539RS00
<i>Manual Non-stop</i>	
SPeria 142 E.....	P143RS143-Ab
<i>Automatic Non-stop</i>	
SP 142 E/ER.....	P5539RS00-A
<i>Automatic Non-stop</i>	
Novacut 142 E.....	P143RS143-Ab
<i>Automatic Non-stop</i>	P145RS145-A
SPanthera 145 PER / SPrintera 145 PER.....	P5539RS00
<i>Manual Non-stop</i>	P5640RS28
SPanthera 145 PER / SPrintera 145 PER.....	P143RS143-Ab
<i>Automatic Non-stop</i>	P145RS145-A
Expertcut 145 PER / Mastercut 145 PER.....	P143RS143-Ab
<i>Automatic Non-stop</i>	P145RS145-A
SP1600.....	P6343RS63
<i>Manual Non-stop</i>	
SP 162 CER.....	P6343RS63
<i>Manual or Automatic Non-stop</i>	
SP 162 CER.....	P164RS164-Ab
<i>Using Rapida 162a Auto</i>	

**HEIDELBERG PRESS****Stratis Pallet**

SM 72, SM 74, PM 74.....	P3022RS00
<i>Manual Non-stop</i>	P3022S00
	P2921RS29N & NS
CD74.....	P79RS00-M
<i>Manual Non-stop</i>	
CD74 (without roller conveyor).....	P79RS00-A
<i>Automatic Non-stop</i>	
SM 102, CD 102.....	P4029RS00
<i>Manual Non-stop</i>	P4231S00
	P4231S42-SR
Racking Board.....	RB4530S00-B
XL 105.....	P107RS00-A
<i>Manual Non-stop feed &amp; Automatic Delivery</i>	P120RS120-A

**MITSUBISHI PRESS****Stratis Pallet**

Diamond 1000.....	P3022RS00
<i>Manual Non-stop</i>	P3022S00
	P2921RS29-N & NS
Diamond 2000.....	P79RS00-M
<i>Manual Non-stop</i>	
Diamond 3000.....	P4029RS00
<i>Manual Non-stop</i>	P4131RS00-N & NS
	P4231S00
Diamond 5000.....	P5038RS00
<i>Manual Non-stop</i>	
Diamond 6000.....	P5539RS00
<i>Manual Non-stop</i>	

**KBA PRESS****Stratis Pallet**

RAPIDA 74, 74G.....	P3022RS00
<i>Manual Non-stop</i>	P3022S00
RAPIDA 104.....	P4029RS00
<i>Manual Non-stop</i>	P4231S00
RAPIDA 105, 105 Universal.....	P4029RS00
<i>Manual Non-stop</i>	P4231S00
RAPIDA105 Auto.....	P106RS00-A
<i>Automatic Non-stop</i>	
RAPIDA 130, 130a.....	P5038RS00
<i>Manual Non-stop</i>	
RAPIDA 142.....	P5539RS00
<i>Manual Non-stop</i>	P5539S00
	P5640RS28
RAPIDA 142 Auto.....	P143RS143-Ab
<i>Automatic Non-stop</i>	
RAPIDA 162, 162a.....	P6343RS63
<i>Manual Non-stop</i>	
RAPIDA 162, 162a.....	P164RS164-Ab
<i>Automatic Non-stop</i>	
RAPIDA 205.....	P205RS205-M
<i>Manual Non-stop</i>	

**MAN ROLAND PRESS****Stratis Pallet**

ROLAND 200.....	P3022RS00
<i>Manual Non-stop</i>	P3022S00
ROLAND 300, 500.....	P3124RS00
<i>Manual Non-stop</i>	P3124S00
ROLAND 700, 600.....	P4029RS00
<i>Manual Non-stop</i>	P4231S00
ROLAND 700.....	P106RS00-A
<i>Automatic Non-stop</i>	
ROLAND 900-4.....	P4433RS00
<i>Manual Non-stop</i>	
ROLAND 900-5 / 800-5.....	P5038RS00
<i>Manual Non-stop</i>	
ROLAND 900-6 / 800-6.....	P5539RS00
<i>Manual Non-stop</i>	P5539S00
	P5640RS56
ROLAND 900-6.....	P143RS143-Ab
<i>Automatic Non-stop</i>	
ROLAND 800-7.....	P6343RS63
<i>Manual Non-stop</i>	

**KOMORI PRESS****Stratis Pallet**

LITHRONE 28, 28P.....	P3022RS00
<i>Manual Non-stop</i>	P3022S00
	P2921RS29-N & NS
LITHRONE SX29.....	P3124RS00 & -N
<i>Manual Non-stop</i>	
LITHRONE 40.....	P4029RS00
<i>Manual Non-stop</i>	P4029S00
Racking board.....	RB4332S43-HD8B
LITHRONE II40, S40.....	P4029RS00
<i>Manual Non-stop</i>	P4029S00
LITHRONE 40SP, 40RP.....	P4029RS00
<i>Manual Non-stop</i>	P4131RS00-N & NS
	P4029S00
LITHRONE 44, 44RP, 44SP.....	P4433RS00
<i>Manual Non-stop</i>	
LITHRONE 50.....	P5038RS00
<i>Manual Non-stop</i>	

